

Simple Rail

SR-29/C58

Kit Instructions

Parts

Qty Part

- 1 62-7 Standard Railing Flange
- 1 C58 Base Plate
- 1 29-7 30-60 Degree Single Socket Tee
- 1 84-7 Malleable Plug
- 1 Post (Cut @ 1000mm)
- 1 Grab Rail
- 1 Allen Key

Tools

- Allen Key (included)
- Rubber Mallet/Hammer (for plugs)
- Drill/Hammer Drill
- Wrench

Hardware (Not included)

- 4 x Sleeve Anchors (For flange on Concrete/Brick)
- 4 x Coach Screws (For flange on Wood)
- 2 x Masonry Screws (For Concrete/Brick wall)
- 2 x 2 1/2" Lag Screws (For Wood wall)

Installation Tips

1. Confirm that you have all the required parts.
2. When installing plugs, place rag or cardboard over plug and gently hammer into place.
3. If installing into concrete or brick, vacuum out debris from drilled out holes before inserting sleeve anchors.
4. If you plan on painting your rail, do so



Step by Step

1. Insert post into 62-7. Tighten set screws loosely.
2. Line up assembled post to desired location. Test grab rail with post, then mark holes for the 62-7 and C58.
3. Disassemble the post and drill the holes for the 62-7 and C58. Secure 62-7 to surface and C58 to wall with relevant hardware.
4. Insert post into 62-7 and add socket of 29-7 to top of post. Tighten set screws loosely.
5. Slide one end of grab rail through the 29-7 on post at desired location and insert other end into C58 on wall. Tighten set screws once complete.
6. Cover 84-7 with a rag or cardboard and gently hammer into place.