

## Simple Table Instructions - STANDARD



### Tools Needed:

Allen Key (Included)  
Screw Driver  
Rubber Mallet (for plugs)  
Level

### Frame Parts

6 x 10-7 Tees  
4 x 61-7 Flanges  
1 x (A) Width Tube  
2 x (B) Depth Tubes  
4 x (C) Leg Tubes

### Footing Parts (one of below)

4 x 77-7 Plastic Plugs  
Or  
4 x 61-7 Flanges

### Tips:

Don't over-tighten the setscrews.  
Tightening a fitting will mark the tube,  
so be careful where you do it.

Need help? Give us a call!

0844 335 8460

- 1) Start by attaching the 10-7 Tees to end of Tube A
- 2) Now slide each Tube B through the 10-7 Tees on Tube A
- 3) Attach the remaining 10-7 Tees to the ends of Tube B.
- 4) Slide Tube C into the 10-7 Tees and leave about 75mm sticking out. Tighten grub screws lightly.
- 5) Attach the 61-7 flanges on the long side of Tube C
- 6) Place your desktop on the ground, with the bottom facing up.
- 7) Flip the tube frame over so that the 61-7 flanges are now lying flat on the bottom of the desktop.
- 8) Move the legs of the frame on the desktop until the flanges are about 100mm from each edge.
- 9) Attach the 61-7 flanges to the desktop with the appropriate fastener (not provided).
- 10) Attach the appropriate footing

- 11) Turn the desk right side up, you're done! You can adjust the individual fittings to make sure that everything is level and square.

### Footing Attachment Guide

#### Plugs

Tap the 77-7 plastic plugs into the bottom of the tube legs.

#### Flanges

Place a 61-7 fitting on each leg and tighten them into place.



[www.simplifiedbuilding.co.uk](http://www.simplifiedbuilding.co.uk)  
0844 335 8460  
[info@simplifiedbuilding.co.uk](mailto:info@simplifiedbuilding.co.uk)